

INSTALLATION INSTRUCTIONS: ANOM2405C

1. Drill a 5/8" (16 mm) diameter hole in the ceiling panel.
2. Install antenna assembly exactly as shown in the diagram for proper performance.
The large metal plate is not supporting the antenna, the washer is providing the support.
3. Attach cable assembly with a N-Male to the antenna's N-Female connector.
(cable sold separately).

